TABLE OF CONTENTS

| 1 | Before driving | Adjusting and operating features such as door locks, mirrors, and steering column | |
|---|---------------------------|---|--|
| | | | |
| 2 | When driving | Driving, stopping and safe-driving information | |
| | | | |
| 3 | Interior features | Air conditioning and audio systems, as well as other interior features for a comfortable driving experience | |
| | | | |
| 4 | Maintenance and care | Cleaning and protecting your vehicle, performing do-it-your- self maintenance, and maintenance information | |
| | | | |
| 5 | When trouble arises | What to do if the vehicle needs to be towed, gets a flat tire, or is involved in an accident | |
| | | | |
| 6 | Vehicle specifications | Detailed vehicle information | |
| | | | |
| 7 | For owners | Reporting safety defects for US owners and seat belt instructions for Canadian owners | |
| | | | |
| | Index | Alphabetical listing of information contained in this manual | |
| | | | |